



# 1 Assembly manual closeable box trike



## Overview of the parts

1. Front panel
2. Right panel
3. Left panel
4. Bench
5. Lock
6. Bracket
7. Sliding Lock





## Step 1: Remove the existing parts

Remove the existing seat and supports on the left and right side. Remove the bolts for the seat.

## Step 2: Pre-assembly left panel

Mount the sliding lock (5) on the left panel (2) with the 4 small screws.




## Step 3: Pre-assembly right panel

Mount the bench magnet on the right panel (3) with the existing screws.


## Step 4: Mount the side panels

Mount the left and the right panel (2 & 3) in the box with the existing screws.



## Step 5: Pre-assembly front panel



## 2 Assembly manual closeable box trike



Mount the lock (4) on the front panel (1).  
Make sure that the hook is facing upwards in the locking position of the lock.

### Step 6: Slide the front panel in

Slide the front panel in the box and make sure the sliding lock fits in the front panel.





### Step 7: Drill holes in the bench

Drill two holes with a diameter of 6 mm in the right side of the existing bench.

### Step 8: Pre-assembly of the bench

Mount the lock bracket (6) on the existing bench with the two bolts and nuts.



### Step 9: Mount the bench

Mount the bench in the box with the original screws.